

BOVIBOOSTER | L4DL

LELY A3 NEXT NOZZLE BAR INSTALLATION INSTRUCTIONS

- DK**
- Start med at rengøre gulvet og risten i robotten grundigt, rengør også under gummimåtten.
 - Bor et 37 mm hul midt for risten så lavt som muligt, ind i robotens teknikskab.
 - Fastgør dysepladens monteringsbeslag på risten. Start med at montere de to aluklodser¹ på monteringsbeslaget² med de medfølgende M8x90mm bolte³ i de næst yderste huller på monteringsbeslaget.
 - Monteringsbeslaget skal monteres så langt tilbage som muligt. Tilspænd de to aluklodser op imod risten.
 - Når monteringsbeslaget er fastgjort, monteres dysepladen⁴. Start med at centrere dysepladen over monteringsbeslaget, monter herefter de tre M8x25 mm bolte⁵ der skal monteres oppe fra, boltene skal tilspændes indtil risten begynder at løfte sig. Tilspænd herefter de to sidste M8x25 mm bolte⁶ op imod dysepladen og slut af med at efterspænde de tre andre.
 - Man kan med fordel tilslutte injektionsslangen på dysepladen, inden den endeligt fastgøres. Omløberen skal tilspændes med håndkraft.
 - Tilslut den blå 12/20 mm PVC slange til injektionsslængens 12 mm slangestuds og den klare 4/6 mm PVC slange til injektionsslængens 4/6 mm push-on nippel. Tilslut også disse slanger til BB Controller'en.
 - Slut af med at indstille dyserne, hvis dette er nødvendigt.
- UK**
- First, clean the robot floor and grate thoroughly, even under the rubber mat.
 - Drill a 37 mm hole for the injection hose into the robot technique cabinet, place the hole in the middle and as low as possible.
 - Attach the nozzle bar mounting bracket on to the grate. Start by mounting the two aluminum blocks¹ on the mounting bracket² with the supplied M8x90 mm bolts³ in the next outermost holes on the mounting bracket.
 - The mounting bracket must be installed as far back as possible. Tighten the two aluminum blocks up against the grate.
 - When the mounting bracket is secured, the nozzle bar⁴ is mounted. Start by centering the nozzle bar over the mounting bracket, and then mount the three M8x25 mm bolts⁵ from above, the bolts must be tightened until the grate begins to rise. Then tighten the remaining two M8x25 mm bolts⁶ up against the nozzle bar, finish by tightening the other three bolts.
 - It may be an advantage to connect the injection hose to the nozzle bar, before the nozzle bar is finally secured. The injector hose nut must be tightened firmly by hand.
 - Connect the blue 12/20 mm PVC hose to the 12 mm hose stud and connect the clear 4/6 mm PVC hose to the 4/6 mm push-on nipple. These hoses must also be connected to the BB Controller.
 - If necessary, finish by adjusting the nozzles.

LELY A3 NEXT NOZZLE BAR.



37 mm hole for injector hose

4/6 mm push-on nipple

12 mm hose stud

Injector hose

