

DK

- UK
- *The Bovibooster start signal for Delaval robots is compressed air operated.*
  - *Connect the included yellow 4/2 mm tube<sup>1</sup> to the air control valve line<sup>2</sup> for the teat disinfection valve, using the included 4 mm push-in tee<sup>3</sup>, see illustration*
  - *Connect the other end to the Bovibooster 4 mm push-in start signal connector<sup>4</sup>, placed in the bottom of the control box, see illustration.*
  - *The valve or connection point for the start signal can vary. Please contact authorized personnel, if you have any questions regarding placement of the valve for teat disinfection spray.*



**Example: Robot connection illustration**  
**OBS! The included hose is yellow**



**Bovibooster start signal 4 mm push-in connector**